



Powerlynk Lynks 8kW SM8.0kWPLL



USER MANUAL SA

www.sunsynkmobile.com / sales@sunsynkmobile.com



INDEX

SAFETY	3	BATTERY COMPATIBILITY	19
General Safety Information	3		
Safety Instructions	3	OPERATION	20
Symbols in the Manual	4	System Flow	20
Symbols in the Product	4	Switching On / Off	21
Product Disposal	5	Home Screen	21
		Home Settings	22
PRODUCT INTRODUCTION	6	Basic Settings	22
		Language Settings	23
BOX CONTENTS	6	Grid Mode Settings	24
		Work Mode Settings	25
TECHNICAL SPECIFICATION	7	System Logger	26
		Advance Settings	27
INSTALLATION	9	Grid Settings	28
Selecting the Mounting Area	9	Battery Settings	28
Mounting the Inverter	10	System Settings	29
Battery Cable Connection	11	Export Control	30
Flow Diagram	12	Export Sell to Grid	30
Connecting to the Mains / Grid	12	Charge From Main	32
Wiring the PV Panels	12	Earth Neutral Bond	32
CT Coil and Load Power Settings	13	Night Power Saving	33
Parallel Operation	14	Setting Details	34
External Battery and Parallel Connections	15		
Load Connection	16	FAULT CODES	37
Grid Connection	16		
Solar Connection	17	COMMISSIONING	39
		Startup / Shutdown Procedure	39
LCD DISPLAY SCREEN	18	Information for Commissioning the Inverter	40
		GFDI Fault	41
FACTORY SETTINGS	19	MAINTENANCE	41
		APPENDIX A	41

SAFETY

General Safety Information

- This device should only be used in accordance with the instructions within this manual and in compliance with local, regional and national laws and regulations. Only allow this device to be installed, operated, maintained or repaired by other person(s) who have also read and understood this manual. Ensure the manual is included with this device should it be passed to a third party.
- **DO NOT** allow minors, untrained personnel, or person(s) suffering from a physical or mental impairment that would affect their ability to follow this manual, install, maintain or repair this device.
- Any untrained personnel who might get near this device while it is in operation **MUST** be informed that it is dangerous and instructed carefully on how to avoid injury.

Safety Instructions



WARNING

HIGH LIFE RISK DUE TO FIRE OR ELECTROCUTION.

The Lynks 8kW can only be installed by a qualified licensed electrical contractor. This is not a DIY product.

Ensure to follow the safety warnings listed below:

- Be sure to read this manual thoroughly before installation.
- Do not attempt to install the inverter by yourself. Installation work must be carried out in compliance with national wiring standards and by suitably qualified personnel only.
- Do not turn on the power until all installation work is complete.
- Do not disassemble the inverter. If you need to repair or maintenance, contact a professional service centre.
- Always use an individual power supply line protected by a circuit breaker and operating on all wires with a distance between contacts of at least 3mm for this unit.
- The unit must be correctly grounded and the supply line must be equipped with a suitable breaker and RCD to protect people.
- Disconnect all wires before performing any maintenance or cleaning to reduce the risk of electric shock.
- The unit is not explosion-proof, so it should not be installed in an explosive atmosphere.
- Never touch electrical components immediately after the power supply has been turned off since the system can still have residual energy, so electric shock may occur. Therefore, after turning off the power, always wait 5 minutes before touching electrical components.
- This unit contains no user-serviceable parts. Always consult an authorised contractor for repairs.






Symbols in the Manual



This symbol indicates information that if ignored, could result in personal injury, physical damage or even death due to incorrect handling.

Symbols in the Product

	Risk of burn.		Keep the equipment well-ventilated.
 	Risk of electric shock. DO NOT touch the terminal or remove the shell within 5 minutes after disconnecting all power.	UKCA	The UKCA marking is used for products placed on the market in Great Britain (England, Scotland and Wales). The UKCA marking applies to most products for which the CE marking could be used.
	The Inverter is heavy and can cause injury if not handled safely.		Do not disassemble or alter the inverter in any way.
	Be careful when touching the inverter! It is an electrical product with risk of electric shock and heating.		ONLY qualified personnel should install or perform maintenance work on the units.
	Do not place near open fire or incinerate. Do not use near heaters or hot temperature sources.		Warranty Void if Seal is Broken.
	Do not stand on.		Keep the product out of reach of children!
	Do not step or put any objects onto the inverter.		Avoid unsuitable shoes for installing and operating the inverter.
	Protective Conductor Terminal or Earth Ground Terminal.		Do not drop, deform, or impact the inverter.
	Single Phase.		Three Phase.
	Do not submerge the inverter in water or expose it to moisture or liquid.		Keep out of reach of children, animals, and insects.

	Do not expose the product to sunlight.		Inverter DC to AC.
	Max. PV input current.		Net Weight in Kilograms.
	BATTERY INPUT Battery Discharge Voltage, Battery Discharge Current, Input Voltage Type, Battery Discharge Power.		PV INPUT PV Input Voltage, Number of MPPT's, MPPT Input Current & Max PV ISC.
	Direct Current.		Indicates that this product is recyclable.
	AC OUTPUT Output Voltage, Input Voltage Type, AC Output Rated Current, Max AC Current, Output Frequency, Max AC ISC, Power Factor & AC Output Rated Power.		CONTINUOUS OUTPUT CURRENT Maximum Continuous Output Current, Output Frequency and Voltage, & AUX (programmable AC output on battery SOC).
	Charging.		Discharging.
	Follow the indicated temperatures.		TEMPERATURE Ambient, Min & Max.
	MANUAL DOWNLOAD Download the latest version of the instruction manual by scanning the QR code.		WARRANTY REGISTRATION Scan the QR code to access our website and sign up for the manufacturer's warranty.
	Do not dispose the device, accessories, and packaging with regular waste. Follow local ordinances or contact the manufacturer for disposal guidance.		Refer to the operating instructions. Contact the supplier within 24 hours if there is anything wrong. In case of leakage contact with eyes or skin, immediately clean with water and seek help from a doctor.
	CE mark is attached to the solar inverter to verify that the unit follows the provisions of the European Low Voltage and EMC Directives.		

Product Disposal

DO NOT dispose of this product with domestic waste!

Electrical devices should be disposed of in accordance with regional directives on electronic and / or electronic-waste disposal. In case of further questions, please consult your supplier. In some cases, the supplier can take care of disposal.

PRODUCT INTRODUCTION

The Lynks 8kW is a highly efficient power management solution that helps users achieve 'parity' targets by optimizing power flow from multiple sources such as solar, mains power (grid), and generators. It intelligently manages the distribution of power based on demand, ensuring effective use of available energy when needed by the utilities.

INTERACTIVE

- Easy and simple to understand LCD display.
- Supporting Wi-Fi or GSM monitoring.
- Built-in MPPT trackers.
- Smart settable 3-stage MPPT charging for optimised battery performance.

COMPATIBLE

- Compatible with main electrical grid voltages.
- 230V single-phase, pure sine wave inverter.

CONFIGURABLE

- Fully programmable controller.
- Programmable supply priority for battery or grid.
- Programmable multiple operation modes: on-grid / off-grid & UPS.
- Configurable battery charging - current / voltage based on the application.

SECURE

- Overload / over-temperature / short-circuit protection.
- Smart battery charger design for optimized battery protection.
- Limiting function installed to prevent excess power overflow to grid.

APPLICATIONS

- Power shedding (home / office / factory).
- UPS (Uninterrupted Power Supply).
- Remote locations with solar.
- Building sites.
- Telecommunication.


BOX CONTENTS

This box contains:

- | | |
|---|--------------------------------------|
| • Lynks 8kW (main unit) | • Wall mounting bracket |
| • Screw pack | • Data logger (Sunsynk Wi-Fi) |
| • CT Coil (2 pin AERO - female connector) | • 1x3 pin AC Load connector (female) |
| • 2 x MC4 connectors | • 1x3 pin AC Grid connector (male) |
| | • 2x Battery Connectors |

TECHNICAL SPECIFICATION

- Pure sine wave inverter with a maximum input power of 10kW.
- MPPT charge controller feature.
- Bi-directional inverter that can rapidly charge external external batteries.



Model	Lynks 8kW
Battery Input Parameters	
Supported Battery Type	Li-Ion or Lead-acid
Nominal Battery Voltage	48V
Battery Input Voltage Range	40~60V
Max. Charge Voltage	≤60V (Configurable)
Max. Charge Current	150A (Configurable)
Max. Discharge Current	180A (Configurable)
Battery Capacity (Recommended)	100~2000Ah
Charge for Li-Ion Battery Pack	Communicating with BMS of Battery Pack
PV String Input Parameters	
Max. DC Input Power	5000W x 2 = 10000W
DC Input Voltage	500V
MPPT Voltage Range	120-450V
Start-up Voltage	150V
Max. Input Current	23A x 2 = 46A (2 MPPT Channels)
AC Output Parameters (Back-Up)(Feed to Essential Load)	
Max. Output Power	8000W
Max. Output Apparent Power	8000VA
Peak Output Apparent Power	16000VA
Max. Output Current	36A
Nominal Output Voltage	220/230/240Vac Single-Phase (Configurable)
Nominal Output Frequency	50/60Hz (+/-0.2%) (Configurable)
Max. Bypass Current	42A
Shift Time (Bypass and Inverter)	10ms
Output THDv (Resistor Load)	<3%
AC Input Parameter (On-Grid)(Bypass to Essential Load & Charge the Battery/Feed to Home Load)	
Max. Input Power	8000W
Max. Output Power (Feed to Home Load)	8000W
Max. Apparent Input Power	8000VA
Max. Apparent Output Power	8000VA
Nominal Input/Output Voltage	220/230/240Vac (Auto Adjusted to Fit Home Grid)
Nominal Input/Output Frequency	50/60Hz (Auto Adjusted to Fit Home Grid)
Max. Bypass Current	42A
Shift Time (Bypass and Inverter)	10ms
Efficiency	
Max. Efficiency	97.6%
Max. Battery to Load Efficiency	94.0%
Europe Efficiency	97.6%
MPPT Efficiency	99.9%

Protection

Integrated


Battery Over-Charge Protection, Battery Low-Voltage Protection, Over-Temperature Protection, Output Over-load Protection, Output Short Circuit Protection

General Information

Operating Temperature Range	-20°C ~ +50°C (>35°C Derating)
Protection Degree	IP41
Net Dimension	570x525x140 mm
Gross Dimension	685x600x220 mm
Net Weight	24.5kg
Gross Weight	28.5kg

INSTALLATION

Selecting the Mounting Area



DO NOT install in the following areas:

- Areas with high salt content, such as the marine environment. It will deteriorate the metal parts and possibly lead to water / dampness penetrating the unit.
- Areas filled with mineral oil or containing splashed oil or steam such as in kitchens. This will deteriorate plastic parts of the unit, causing those parts to fail or allow water /damp to penetrate the unit.
- Areas that generate substances that adversely affect the equipment, such as sulphuric gas, chlorine gas, acid, or alkali. These can cause the copper pipes and brazed joints to corrode and fail to conduct electricity reliably.
- Areas that can cause combustible gas to leak, which contains suspended carbon-fibre, flammable dust or volatile inflammability such as paint thinner or gasoline.
- Areas where there may be gas leaks and where gas may settle around the unit, as this is a fire risk.


- Areas where animals may urinate on the unit or ammonia may be generated.
- High altitude areas (over 4000 metres above sea level).
- Environments where precipitation or humidity are above 95%.
- Areas where the air circulation is too low.

ALSO CONSIDER:

- Installing the indoor unit, outdoor unit, power supply cable, transmission cable and remote control cable at least 1 metre away from any television or radio receiver. This will prevent TV reception interference or radio noise. This will also prevent radio signal interference from external units that might interfere with the Wi-Fi or GSM monitoring.
- If children may approach the unit, take preventive measures so that they cannot reach and touch the unit.
- Install the indoor unit on the wall where the height from the floor is higher than 1600mm.
- For proper heat dissipation, allow a clearance of approximately 500mm to the side, 500mm above and below the unit and 1000mm to the front of the unit.

Mounting the Inverter

- Select a location that provides adequate support for the weight of the inverter.
- Install this inverter so that the LCD screen is eye-level for easy operation.
- An appropriate ambient temperature lies between $-20 \sim 50^{\circ}\text{C}$ for optimal operation. Battery charging temperature range lies between $0^{\circ}\text{C} \sim 50^{\circ}\text{C}$.
- Ensure other objects and surfaces are outside of the recommended spaces (500mm each side / above and below / front) to guarantee heat dissipation and easy access to the wiring / cabling.




CAUTION


Risk of Injury (Heavy Object)

Remember that this inverter is heavy, so users must be careful in handling the unit during installation especially when mounting or removing from a wall.

Battery Cable Connection



Flow Diagram



Connecting to the Mains / Grid

1. Connect the Lynks 8kW Hybrid Inverter to the electrical grid via the *grid ports*, using a suitable RCD and a 50A fuse on the consumer board.
2. Now, connect only the essential loads to the *load ports* (output) to a secondary consumer board, considering the maximum limit of 8 kW.
3. Ensure the main consumer unit and the secondary consumer unit are correctly grounded to the Lynks 8kW.

Wiring the PV Panels


- The Lynks 8kW has two MPPT controllers with a maximum input current of 46A (2 x 23A).
- Before connecting to PV modules, install a separate DC circuit breaker between the inverter and PV array.
- To avoid any malfunction, **DO NOT** connect any PV modules with possible current leakage to the inverter. For example, grounded PV modules will cause current leakage to the inverter.
- Also, the open-circuit voltage (Voc) of the PV modules does not exceed the maximum input voltage of the inverter. Also, the Voc of the PV array should be higher than the minimum starting voltage of the inverter.
- Connect the PV panels into the MC4 connectors.

CT Coil and Load Power Settings

The CT coil is one of the most important parts of the Lynks 8kW. This device reduces the power of the inverter to prevent feeding power to the grid. This is also known as zero export.

- Fit the coil (sensor) around the live cable on the main fuse feeding the building and run the cable back to the inverter. This cable can be extended up to an extra 10m using a similar cable.
- Connect the other end of the CT coil into the inverter terminals marked as *CT coil*.

Fit around positive cable feeding the building BETWEEN the meter and main fuse.



You can access the *CT Coil Screen* directly from the *Home Screen* by pressing the Home/Back button:

SUN  SYNK		
CT Power	Essential Load Power	Home Load Power
30W	1000W	4800W
Work Mode: Standalone Input Trickle Feed: 30W Export Control: Zero Export Earth Neutral Bond: Enable Night Power Saving: Enable		

You can access the External Battery Pack page by pressing the Home/Back button again:

SN: XXXXXXXXXX

SUN  SYNK

External Battery Pack

Capacity: 100Ah SOC: 65%

Voltage: 53.4V Current: 30A

Charge Voltage Limit: 57.6V

Discharge Voltage Limit: 45.0V

Charge Current Limit: 50A

Discharge Current Limit: 100A

Temp: 31.2°C Alarm: 0x0000

Parallel Operation

In order to connect Lynks 8kW inverters to operate in parallel, you need to set up the work mode configuration for each the inverter. Basically, you have to set which inverter will be the master and which will be the slaves, and then make the connections described in section External Battery and Parallel Connections.

Basic Settings

Set Time 15:16

Set Date 19-05-2023

Backlight On

Work Mode Master

SOC/Voltage Voltage

Factory Reset No

Basic Settings

Set Time 15:16

Set Date 19-05-2023

Backlight On

Work Mode Slave 02

SOC/Voltage Voltage

Factory Reset No




WARNING

To ensure the proper functioning of the parallel operation, it is important first to establish the work mode for both the Master and Slave inverters and then make the necessary wiring connections.


If you make the connection prior to changing the work mode, an F15 error will be displayed on the Fault Codes page. In the event of this error, please maintain the connection and proceed to the settings to modify the work mode as presented above, and wait approximately 3-4 minutes. After that, the device should return to its normal working condition, with the error cleared.

External Battery and Parallel Connections


Inverter Unit: 1 | Battery: 1




Inverter Unit: 1 | Battery: 2




Inverter Unit: 1 | Battery: 1




Inverter Unit: 2 | Battery: 2




Inverter Unit: 3 | Battery: 1




Inverter Unit: 3 | Battery: 2




Inverter Unit: 2 | Battery: 1
(Shows CT Coil Connection + Master&Slave)




Inverter Unit: 2 | Battery: 2
(Shows Batteries connected in parallel)




Inverter Unit: 3 | Battery: 6
(Shows External batteries can be installed into each inverter)



Load Connection



Grid Connection




Solar Connection



LCD DISPLAY SCREEN

The LCD display screen is situated on the front of the Lynks 8kW, this is where you can control and operate the system.



1. **Power** - to turn the system on / off.
2. **Settings / Select** - to operate the settings menu & to select.
3. **Up** - to navigate up.
4. **Down** - to navigate down.
5. **Home / Back** - to go back to the home menu & to navigate backwards.

TYPE	INDICATION	DESCRIPTION
BATTERY	GREEN	CHARGING
	BLUE	DISCHARGING
AC	GREEN	AC CONNECTED
	OFF	AC OFF
SOLAR	GREEN	SOLAR ON
	OFF	SOLAR OFF
NORMAL	GREEN	INVERTER RUNNING
	RED	SYSTEM FAULT
	OFF	INVERTER NOT RUNNING

FACTORY SETTINGS


Battery Settings		Default Setting		
Low Battery Cut Off		45.0V		
Reboot Voltage		50.0V		
Maximum Charge Current		50A		
Charge from MAIN		YES		
Float Charge Voltage		56.0V		
Active		ON		
System Configuration		Default Setting		
Maximum Discharge Current		100A		
Maximum Battery Voltage		56.0V		
Import Trickle Feed		30W		
Export Control		Zero Export		
Earth Neutral Bond		Enable		
Night Power Saving		Enable		
Grid Settings		Default Setting		
Maximum Grid Voltage		253V		
Minimum Grid Voltage		195.5V		
Maximum Grid Frequency		52.0Hz		
Minimum Grid Frequency		47.5Hz		
System Controller			Default Setting	
00:00	6:00	3000W	52.0V	Y
6:00	12:00	3000W	52.0V	Y
12:00	18:00	3000W	52.0V	Y
18:00	23:59	3000W	52.0V	Y

BATTERY COMPATIBILITY

The following batteries are compatible with Sunsynk Mobile Lynks Inverter:

- SUN-BATT-5.32
- SUNSYNK-L5.3
- L051069-A

System Flow



Switching On / Off

Once the inverter has been correctly installed and the batteries are connected, press the *on / off button* (located on the front of the case) to turn on the system.

Home Screen

SUN  SYNK®	
Solar 1:3500W/400V Solar 2:3500W/400V	Inverter Power/Voltage 7680W/ 232V
Battery Voltage/Soc 52.6V/ 21%	Grid Voltage/Frequency 232V/ 50.0Hz
System Mode / Current DisC/ 12.93A	DATE: 10-09-2024 TIME: 17:12 : 51 Temp: 37.5°C

What does this page display?

Solar MPPT Input Power 1&2

Battery Voltage

System Status

Inverter Current Power

Grid Voltage and Frequency

Date / Time


What you can do from this page

If you press the select button you can navigate to the *basic setup menu*

If Sunsynk Connect has been connected, the WI-FI icon appears

Access the CT screen by pressing the Home/Back button

Home Settings





What does this page display?

- Basic setting icon
- System logger icon
- Fault codes icon
- Advanced settings icon
- Language settings icon

What you can do from this page

You can navigate through the functions by clicking on each icon

Basic Settings



What does this page display?

- Time
- Date
- Backlight on / off
- Work Mode
- SOC/Voltage
- Reset

What you can do from this page

Set the system's time

Set the system's date

Set backlight

Set the workmode

Set the system SOC/Voltage

Reset to factory default settings

After changing the settings, do not forget to click *save settings*.

Basic Settings

Save Settings?

YES**NO**

Language Settings

Change the language settings via the "Basic Settings" page by pressing the "Factory Reset" button. Then a password input page will be shown. The default password is "1234".

Basic Settings

Set Time	15:16
Set Date	15-05-2023
Backlight	On
Work Mode	Standalone
SOC/Voltage	SOC
Factory Reset	No

SUN  SYNK®

Please Input the Password

Then select the language according to your country or region by swiping right.

SUN  SYNK®



Select Your Country or Region

English

SUN  SYNK®



Select Your Country or Region

BUL

SUN  SYNK®



Select Your Country or Region

CZ

Grid Mode Settings

Change the language settings via the “Basic Settings” page by pressing the “Factory Reset” button. Then a password input page will be shown. The default password is “1234”.

Basic Settings

Set Time

15:16

Set Date

15-05-2023

Backlight

On

Work Mode

Standalone

SOC/Voltage

SOC

Factory Reset

No

SUN  SYNK®

Please Input the Password

Then select the grid mode according to your region by swiping right.

SUN  SYNK®



Select Your Grid Mode

G98/G99

SUN  SYNK®



Select Your Grid Mode

VDE

SUN  SYNK®



Select Your Grid Mode

NRS097

SUN  SYNK®



Select Your Grid Mode

IEC61683

Work Mode Settings

Change the work mode settings via the “Basic Settings” page by pressing the “Work Mode” button. Then a password input page will be shown. The default password is “1234”.

Basic Settings

Set Time	15:16
Set Date	15-05-2023
Backlight	On
Work Mode	Standalone
SOC/Voltage	SOC
Factory Reset	No

SUN  SYNK®

Please Input the Password

Then, the "Work Mode Settings" page will display.

Work Mode Settings

Standalone

Single-Phase Master

Single-Phase Slave02

What does this page display?

The Work Mode selected

Single-Phase Master

Single-Phase Slave number

What you can do from this page

Change the number of Slave Inverters (maximum 15 slaves)

System Logger

System Logger



Solar ProductionGrid Production

SN: XXXXXXXXXX
DEVICE MODEL: SM8.0KWPLL
DEVICE POWER: 8.0KW
MAIN VERSION: VX.X-XXXX
LCD VERSION: VX.X-XXXX

Solar Production

Daily Energy1KWh

Monthly Energy30KWh

Year Energy3600KWh

Total Energy7200KWh

Grid Production

Daily Energy1KWh

Monthly Energy30KWh

Year Energy3600KWh

Total Energy7200KWh

What does this page display?

Solar production icon

Grid production icon

What you can do from this page

Daily solar energy produced

Monthly solar energy produced

Yearly solar energy produced

Total solar energy produced


Daily grid energy used

Monthly grid energy used

Yearly grid energy used

Total grid energy produced

Advance Settings



What does this page display?

Grid Settings page icon

System Configuration page icon

Battery Settings page icon

System Controller page icon

What you can do from this page

You can access the grid, system, inverter, and battery setting pages.

Grid Settings

Grid Settings	
Grid Mode	NRS097
Max Grid Volt	253V
Min Grid Volt	195.5V
Min Grid Freq	47.5Hz
Max Grid Freq	52.0Hz
Voltage	AC 230V
Frequency	50Hz

What does this page display?

Grid Mode

Maximum grid voltage allowed

Minimum grid voltage allowed

Minimum grid frequency

Maximum grid frequency

Battery Settings

Battery Settings	
Low Battery Cut Off	10%
Reboot Battery	20%
Max Charge Current	50A
Charge from AC	Yes
Low Battery	15%
Float Charge	56.0V

Battery Settings	
Low Battery Cut Off	45.0V
Reboot Battery	50.0V
Max Charge Current	50.0A
Charge from AC	Yes
Low Battery	49.0V
Float Charge	56.0V

What does this page display?

Low battery SOC/Voltage

Reboot SOC/Voltage

Maximum charge current

Charge from the mains

Low Battery SOC/Voltage

Float charge SOC/Voltage

What you can do from this page

Set a *low voltage* cut-off for the batteries. Before setting this, please refer to the battery characteristics.

The *reboot voltage* is the voltage that the batteries must reach before the inverter switches on again.

Maximum charge is the maximum current that the system will provide to charge the batteries. This is normally rated at 0.5C, the battery's Ah (s) x 0.5. For example, if you have installed a 20Ah battery, then the maximum charge current should be set at 10A. The lower the setting, the longer the batteries will last.

If *charge from the mains* is set as *YES* the batteries will charge from the mains grid.

Float charge voltage must be set accordingly to the specifications of the battery used.

Set the Low Battery Voltage to set the point where Low power mode will take affect.

PLEASE NOTE

If the Charge from AC is set to No, the battery cannot be charged from AC GRID. Otherwise, the battery can be charged from AC GRID.

System Settings

System Config	
Max Discharge Current	100A
Max Battery Voltage	56.0V
Import Trickle Feed	30W
Export Control	Zero Export
Earth Neutral Bond	Enable
Night Power Saving	Enable

What does this page display?

Maximum discharge current

Maximum battery voltage

Input power to prevent export

Export Control

Earth bonding

Night Power Shaving

What you can do from this page

Set the maximum discharge current from the batteries.

Set the maximum voltage the batteries should be charged to.

Set the "Import Trickle Feed" from GRID, minimum 20W.

Set the "Export Control". Could be "UPS", "Zero Export", and "Sell".

If Earth Neutral Bond is enabled, the relay will make and earth neutral bond on the load port of the inverter after the grid power fails. This is for earth leakage devices to function correctly on this island circuit.

The Night Power Saving can be set to "Enable" or "Disable".

Export Control

The Export Control can be set as "UPS", "Zero Export" and "Sell".

1. "UPS"

When the "Export Control" is set to "UPS", the inverter will not export power to the home load via the "GRID" connector, just power the essential load that is connected to the "LOAD" connector. When the "Charge from Main" is set to "Yes", the battery can be charged from the main AC and PV, and the charge time period can be set via the "System Controller" page.

In the "System Controller" page, when the "charge" option is set to "N", the inverter will not be charged by the main AC from "Start Time" to "Stop Time" in this time period. When the "Charge" option is set to "Y", the battery will be charged by the main AC from "Start Time" to "Stop Time" to "Vol" setting value in this time period.

2. "Zero Export"


When the "Export Control" is set to "Zero Export", the inverter will export power to the home load via the "GRID" connector and power the essential load that connected to the "LOAD" connector at the same time. The export power to the home load will not exceed the total power of the home load, so there is no exceeded power feed out, this is called "Zero Export". A CT (Limit) must be connected to the inverter in this work mode.

3. "Sell"


When the "Export Control" is set to "Sell", the inverter will sell back any excess power produced by the solar panels to the grid. The power selling time and power settings are determined by "System Controller".

Export Sell to Grid

1. Press the Settings button on the main screen.



2. Select Advanced Settings.



3. Select "System Config". In the "Export" option, you can select the "UPS", "Zero Export" and "Sell". If you want to sell electricity, choose "Sell".

Advance Setting



Grid Settings



Battery Settings



System Config



System Controller

System Config

Max Discharge Current	100A
Max Battery Voltage	56.0V
Import Trickle Feed	30W
Export Control	UPS
Earth Neutral Bond	Enable
Night Power Saving	Enable

System Config

Max Discharge Current	100A
Max Battery Voltage	56.0V
Import Trickle Feed	30W
Export Control	Zero Export
Earth Neutral Bond	Enable
Night Power Saving	Enable

System Config

Max Discharge Current	100A
Max Battery Voltage	56.0V
Import Trickle Feed	30W
Export Control	Sell
Earth Neutral Bond	Enable
Night Power Saving	Enable

Which operating mode the machine is working in is shown in the following screens:

SUN SYNK

CT Power	Essential Load Power	Home Load Power
30W	1000W	4800W

Work Mode: Standalone
Input Trickle Feed: 30W
Export Control: UPS
Earth Neutral Bond: Enable
Night Power Saving: Enable

SUN SYNK

CT Power	Essential Load Power	Home Load Power
30W	1000W	4800W

Work Mode: Standalone
Input Trickle Feed: 30W
Export Control: Zero Export
Earth Neutral Bond: Enable
Night Power Saving: Enable

SUN SYNK

CT Power	Essential Load Power	Home Load Power
30W	1000W	4800W

Work Mode: Standalone
Input Trickle Feed: 30W
Export Control: Sell
Earth Neutral Bond: Enable
Night Power Saving: Enable

The power selling time and power settings are determined by the setting screen below.

System Controller					
	Time Start	Time Stop	Power	%/Voltage	Charge
1	00:00	06:00	3000W	52.0V	Y
2	06:00	12:00	3000W	52.0V	Y
3	12:00	18:00	3000W	52.0V	Y
4	18:00	23:59	3000W	52.0V	Y

PLEASE NOTE

This would only allow users to control the amount of power sold from the power stored in the pack. Any power from the PV above a set voltage or SOC is sold to the grid.

Charge From Main

The Charge from Main can be set to "Yes" or "No". When it is set to "Yes", the inverter can be charged by the main AC and PV. When it be set to "No", the inverter will just can be charged by PV, and can't be charged by the main AC.

Charge from AC

Yes

Charge from AC

No

When the "Charge from Main" is set to "Yes", the inverter can be charged from the main AC and PV, and the charge time period can be set via the "System Controller" page.

In the "System Controller" page, when the "charge" option is set to "N", the inverter will not be charged by the main AC from "Start Time" to "Stop Time" in this time period. When the "Charge" option is set to "Y", the inverter will be charged by the main AC from "Start Time to "Stop Time" till to the "Vol" setting value in this time period.

Earth Neutral Bond

The Earth Neutral Bond can be set to "Enable" or "Disable". When is set to "Enable", this will provide the earth is connected to GRID earth when GRID has power. When it is set to "Disable", this function will not be available.

Earth Neutral Bond

Enable

Earth Neutral Bond

Disable

Night Power Saving

The Night Power Saving can be set to "Enable" or "Disable". When is set to "Enable", the Night Power Saving function will be available. When it is set to "Disable", this function will not be available.

PLEASE NOTE

"Night Power Saving" just can work when the "Charge from AC" is set to "No" and there is no PV power input.

The Night Power Saving working mode is described as follow:

1. First, you need set the "Low Battery Voltage" value at the "Battery Settings" page of the LCD display.
2. Then you need to set the "Night Power Saving" time periods and the value of "Vol" on the "System Controller" page.

There are 4 time periods, the inverter will discharge the battery till the battery voltage is equal to the value set at "Vol" section, if the values set are smaller than the value that set at "Low Battery Voltage", when the battery voltage is equal to this value of "Low Battery Voltage", then the inverter will stop its DC to DC converting, and the essential load connected to the "LOAD" connector will just be powered by the main AC. Because the most standby power consumption of the inverter is caused by the inverter's DC to DC converting, so when the inverter stops its DC to DC converting, the standby power of the inverter will be much lower, this can save a lot of power consumption.

PLEASE NOTE

Please remember that when the inverter is working on the "Night Power Saving" state, when the main AC is off, the UPS function shift time will be longer, can't be immediate, it will take around 30 seconds.

When there is PV power input, then the inverter's DC to DC converting will work again, because without this converting, the batter packs can't be charged.

Setting Details

1. UPS Mode

This mode function is set, the inverter output is from the load only and will not export any power to the GRID even if it is connected. Set the Charge from AC by "Yes" and Export Control set by "UPS".

Battery Settings	
Low Battery Cut Off	45.0V
Reboot Battery	50.0V
Max Charge Current	50.0A
Charge from AC	Yes
Low Battery	49.0V
Float Charge	56.0V

System Config	
Max Discharge Current	100A
Max Battery Voltage	56.0V
Import Trickle Feed	30W
Export Control	UPS
Earth Neutral Bond	Enable
Night Power Saving	Enable

Set the time to keep to charge the battery at the %voltage. If PV is not connected, suggest to set %voltage to 56V and set all time range to Y. Start to charge battery time by selecting the Charge Y or N

System Controller				
	Time Start	Time Stop	Power	%/Voltage Charge
1	00:00	06:00	3000W	100% Y
2	06:00	12:00	3000W	100% Y
3	12:00	18:00	3000W	100% Y
4	18:00	23:59	3000W	100% Y

2. Zero Export Mode

This mode function allows the inverter to export power to the home load via the "GRID" connector and power the essential load connected to the "LOAD" connector simultaneously. When zero export is ON, the inverter will export energy to the grid. The maximum power will not exceed the total load power of the grid.

Battery Settings

Low Battery Cut Off	45.0V
Reboot Battery	50.0V
Max Charge Current	50.0A
Charge from AC	Yes
Low Battery	49.0V
Float Charge	56.0V

System Config

Max Discharge Current	100A
Max Battery Voltage	56.0V
Import Trickle Feed	30W
Export Control	Zero Export
Earth Neutral Bond	Enable
Night Power Saving	Enable

System Controller

	Time Start	Time Stop	Power	%/Voltage	Charge
1	00:00	06:00	3000W	52.0V	Y
2	06:00	12:00	3000W	52.0V	Y
3	12:00	18:00	3000W	52.0V	Y
4	18:00	23:59	3000W	52.0V	Y

3. Night Power Saving

When there is no PV, and the battery is not charged from AC, the output power will be to the load from the battery. When the battery level is equal to the battery set in the system control in that time period, and it is set to Y, then the inverter will run at a low power level from GRID to maintain the battery level is not dropped to shut down the inverter. The load power consumption will come from GRID. The setting will be as below.

Battery Settings	
Low Battery Cut Off	45.0V
Reboot Battery	50.0V
Max Charge Current	50.0A
Charge from AC	No
Low Battery	47.0V
Float Charge	56.0V


System Config	
Max Discharge Current	100A
Max Battery Voltage	56.0V
Import Trickle Feed	30W
Export Control	Export
Earth Neutral Bond	Enable
Night Power Saving	Enable

System Controller				
	Time Start	Time Stop	Power	%/Voltage Charge
1	00:00	06:00	3000W	47V Y
2	06:00	12:00	3000W	47V Y
3	12:00	18:00	3000W	47V Y
4	18:00	23:59	3000W	47V Y

If the low battery voltage is set higher, the %voltage will be placed higher accordingly.

FAULT CODES

To check fault codes, click on the *Fault Codes* icon on the *Home Settings* menu.



If any of the fault messages listed in the following table appear on your inverter and the fault has not been removed after restarting, please contact your local vendor or service centre. The following information is required:

1. Inverter serial number.
2. Distributor or service centre of the inverter.
3. On-grid power generation date.
4. The problem description (including the *fault code* and *indicator status* displayed on the LCD) is as detailed as possible.
5. Your contact information.

Error Code	Display Error	Potential Method for Measurement and Fix
F07	DC/DC_Softstart_Fault	1. Startup problems, replace the control board, if not, remove the motherboard to measure the MOS tube is in good condition.
F10	AuxPowerBoard_Failure	1. Power supply failure, update power board.
F13	Working mode change	Inverter work mode changed: 1. Reset the inverter. 2. Seek help from Sunsynk Mobile.
F15	Short circuit protecting	Short circuit fault: 1. Maintain the connection. 2. Proceed to the settings to modify the work mode. 3. Wait approximately 3-4 minutes. 4. The device should return to its normal working condition, with the error cleared. 5. Seek help from Sunsynk Mobile.
F18	AC over current fault or hardware	AC slide over current fault: 1. Check if the backup load power is within the range of the inverter. 2. Restart and check if it is normal.

Error Code	Display Error	Potential Method for Measurement and Fix
F20	DC over current fault of the hardware	DC over current fault: 1. Check PV module and battery connections. 2. Reset the system.
F23	AC leakage current is trans over current	Leakage current fault: 1. Check the PV module and inverter cables. 2. You may have a faulty PV panel (earth short). 3. Restart inverter.
F24	DC insulation impedance failure	PV isolation resistance is too low: 1. Check if the connection of PV panels and inverter are firmly connected. 2. Check if the earth bond cable on inverters is connected to the ground.
F26	The bus bar is unbalanced	1. Please wait 5 minutes to see if it returns to normal. 2. Fully reset the inverter.
F29	ECAN communicate	1. When in parallel mode, check the parallel communication cable connection and hybrid communication address settings. 2. During the parallel system startup period, inverters will report F29. When all inverters are in ON status, it will disappear automatically; 3. If the fault exists, please contact us for help.
F30	Load current exceeding	1. Try to reduce the load power. 2. Seek help from Sunsynk Mobile.
F34	Over Load Protection	1. Reduce appliance power on LOAD side (system will auto-reboot in 2 minutes).
F35	No AC grid	1. Check if the inverter's connected to the AC grid . 2. Check if the RSCD had not tripped. 3. Check if the switch and fuses between the inverter and grid are all switched on.
F37	Battery activation overcurrent	1. System will auto-reboot in 2 minutes.
F39	DC-DC over current	1. Push the power button of the inverter to restart it, system will auto-reboot in 2 minutes.
F40	DC over current	1. If the battery SOC shows 0, turn off the unit and restart it
F41	Parallel system stop	1. Check the hybrid inverter working status. If there's 1pcs hybrid inverter is in OFF status, the other hybrid inverters may report F41 fault in parallel system. 2. If the fault exists, please contact us for help.
F42	AC line low voltage	Grid voltage fault: 1. Check if the voltage is in the range of standard voltage in specification, this can be adjusted via the grid set up page. 2. Check if grid cables are correctly connected.
F45	AC line HIGH voltage	1. Grid exceeds 251V, and the inverter switch is off 2. Grid exceeds 251V, and the inverter switch is on, but the battery is drained

Error Code	Display Error	Potential Method for Measurement and Fix
F47	AC over frequency	Grid voltage fault: 1. Check if the voltage is in the range of standard voltage in specification, this can be adjusted via the grid set up page. 2. Check if grid cables are correctly connected.
F48	AC lower frequency	Grid frequency out of range: 1. Check if the frequency is in the range of specification. 2. You may need to adjust the frequency on the grid set up page.
F55	DC busbar voltage is high	User: External Battery Input voltage is high 1. Installer: check inverter's bus voltage might be too high. Observe the battery voltage value on the LCD (the value will be restored automatically if it is normal), if it is not normal for a long period, you have to check the control board or the voltage acquisition part of the motherboard.
F56	DC bus bar voltage is too low	Battery low voltage: 1. Check if the battery voltage is too low. 2. If the battery voltage is too low use the PV or grid to charge the battery. 3. Check the battery BMS. Important: Especially with lithium batteries, ensure that the batteries Max. discharge current or power specification is the same or higher than the inverter specification.
F60	Smoke alarm	When the smoke alarm is lifted, use the App to restart the inverter (Refer to the relevant content of the App user manual).
F61	Bus one shutdown	1. Reset the inverter. 2. Seek help from Sunsynk Mobile.
F62	DRMs0 stop	Reserved Error code
F63	FAN Error	1. A technician needs to check the internal fan wire or replace fan. 2. Seek help from Sunsynk Mobile.
F64	Heat sink high-temperature failure	Heat sink temperature is too high: 1. Check if the working environment temperature is too high. 2. Turn off the inverter for 30 minutes and restart.

COMMISSIONING

Startup / Shutdown Procedure

The inverter must be installed by a qualified / licensed electrical engineer in accordance to the countries wiring regulations.

Only after the engineer has completed the *earth bond*, RCD and earth leakage tests, check the solar panel Voc voltage (must not exceed 450V) and check the battery voltage. Then, the inverter can now be switched on.

Power On Sequence:

1. Press the start button to on position.
2. Switch on AC.
3. Switch on the DC (PV isolator).

Shutdown Sequence:

1. Switch off the PV isolator.
2. Switch off AC.
3. Press the start button to off position.

Information for Commissioning the Inverter

After you have successfully powered up the inverter, the inverter must be programmed and set up as per the programming feature above.

	Check the <i>earth bond</i> on the solar panels.	Check the Voc does not exceed 450V.	
	Measure the supply voltage, check it matches the settings of the inverter.	If it falls out of the setting range it will cause the inverter to shut down and alarm.	See grid set up page.
	Check the battery charge and discharge is within the C rating of the battery. Too high will damage the battery.		Check the battery BMS is communicating with the inverter.
	This is the heart of the system, this controls everything.	Ensure you are familiar with this, if you fully understand the controller you will fully appreciate the capabilities of there inverter.	
	Familiarise yourself with common fault codes.		

GFDI Fault

Before the inverter starts to connect to the grid, the inverter will first detect the impedance of PV + to ground, and the impedance of PV – to ground. If any of these impedance values is less than 33k, the inverter will not connect to the grid and will report an error F24 on its LCD.

MAINTENANCE

The inverter is low maintenance. However, it is important that at least twice a year (for dusty environments this may need to be carried out weekly) all the cooling fans and air ducts are cleaned and dust free.

Check if there are no fault codes and lithium battery communication is correct.

Weekly cleaning statement: suggest micromesh filters as an available option. Micro insects here are a real problem.

APPENDIX A

If an external residual current device (RCD) is used, a device of type (A / AC, etc) should be employed, with a tripping current of 30mA or higher.

Use of RCDs

Residual current devices (RCDs): An RCD dedicated for an IES may be used to meet the mechanical cable protection requirements and isolation requirements of BS 7671 for the cable from the switchboard to the IES. If an RCD is used, the RCD shall:

1. Disconnect all live conductors (including the actives and neutral).
2. Be of the type specified in the inverter manufacturer's instructions or as labelled on the inverter.

We recommend the use of an RCD on all circuits and sub circuits connected to the Sunsynk Mobile inverter. Residual current breaker with overcurrent protection (RCBO).

Earth-leakage protection class	Type A
Earth-leakage sensitivity	30mA
Curve code	C
Network type	AC
Poles description	2P
Earth-leakage protection time delay	Instantaneous

For more information, training videos, software upgrades, help line or forum please refer to <http://www.sunsynkmobile.com> - Tech Support (Do not forget to register first on the website).



Contact Us

Call +44 151 832 4300 **Email** sales@sunsynkmobile.com **Website:** www.sunsynkmobile.com

Address HK: Room 702-704, 7/F Texwood Plaza, 6 How Ming Street, Kwun Tong, Kowloon, Hong Kong.

UK: Sunsynk UK Ltd, 17 Turnstone Business Park, Mulberry Avenue, Widnes, Cheshire, WA8 0WN.

SA: Unit 2, 3 & 4, 80 Highview Blvd, Ferndale, Randburg, 2160, South Africa.

NL: Sunsynk NL BV, Henri Wijnmalenweg 8, 5657 EP Eindhoven, Netherlands.

AU: Level 1, 982-988 Wellington Street, West Perth WA 6005, Australia.

ES: Tafetana, 32 P.I. Las Andoriñas 38639 Las Chafiras Santa Cruz de Tenerife.

US: 100 S. Ashley Drive, Suite 600, Tampa, Florida, 33602, United States of America.